




OWNER'S MANUAL



THE MODERN BOOMBOX



ON/OFF POWER SWITCH
BATTERY CHARGING PORT



AUDIO INPUT

Connecting audio to this HiFi Case is easy. Choose your laptop, iPod, tablet, iPhone, CD player, walkman etc... press play and turn your volume up. Then proceed to connect as follows:

BLUETOOTH INPUT (SURE HIFI)

Push the power toggle switch to the ON position then go to the Bluetooth settings on your phone or laptop. Choose HIFI CASE from the list of available Bluetooth devices.

ANALOG INPUT

Plug in to the headphone jack on your device using the supplied 1/8th stereo jack and plug the other end into the HiFi Case audio input. (always make sure to turn off Bluetooth switch when using aux in)

BATTERY

The internal Lithium Ion rechargeable battery will run up to 15 hours on a good charge. We recommend you keep your HiFi Case charged up as much as possible to maintain battery life.

POWER INPUT

To charge your HiFi Case, plug in the supplied power cable to the battery charging port located on the right side.

pro tip: if you happen to misplace your power cable you can order a replacement through contact@thehificase.com

AMP CONTROLS

This HiFi Case uses a simple toggle switch located on the right side of the boombox.

Toggle the amp to on and then turn the silver volume knob clockwise to increase the volume. 0 volume is to the left and 10 is to the right. The sweet spot for this device is around 6, which will fill a small living room with sound.

pro tip: consider turning the HiFi Case off after every use to conserve battery life.

CABLE INCLUDED

This HiFi Case comes with the following 3.5mm stereo audio and power cable

STEREO AUDIO CABLE

